# Audio Control Station

The **Device Grid** displays icons indicating the connection and playback state of the iPods. Clicking an icon shows details about that iPod in the Device Panel.

The **Device Panel** displays detailed information about the selected iPod such as the currently playing track, the remaining and elapsed time, and the battery and volume levels. Clicking a track name from the scrollable list will start playing audio.

Warning icons indicate low battery or volume levels.

Playback icons indicate

Playing

Paused

Stopped

Progress bars indicate time elapsed and time remaining.

Numbers indicate the iPod ID (101 to 116).

Grayed iPod icons indicate devices that are not connected.

101

Device 101

Currently Playing:	**Exercise**
	01 - Getting Started
Battery Level:	**51 %**
Volume Level:	**95 %**
Time Remaining:	**4:50**
Time Elapsed:	**1:55**

Stop Pause Resume

■ **Exercise**
→ *01 - Getting Started*
→ *02 - Guidelines to Promote Safe and Effective Exercise*
→ *03 - Adding Strength Training*
■ **Nutrition**
→ *04 - Eating Right for Heart Health and Fitness*
→ *05 - Know What You're Eating - Food Labels*

The name of the currently playing track.

The battery and volume levels—and warnings ⚠.

The remaining and elapsed playback time.

Click here to stop, pause, or resume playback.

Click and drag to scroll through the tracks.

Click a track name to start playing audio. This will stop audio already in progress.